



# FLASK

## Powerbank

Thanks for choosing our power bank. Please read the whole instruction booklet to ensure the best possible use of your product. Only use the included cables. Depending on the charging station, hissing could be heard for a short time at the start of the charging process. After not using the powerbank for a longer time the battery can be fully discharged. In this case, there can be a delay until the charging LED is flashing. The powerbank needs a couple of hours until it is fully charged, depending on your power supply.

### Product specification

1. Built-In battery:

The capacity of the 3.7V lithium-ion-battery is 20.000 mAh.

The remaining battery charge is shown by a seven-segment display (0-100%).

You can charge multiple devices at once using both USB ports (2x2.1A).

Most Apple and Android devices like tablets and mobile phones can be charged using the FLASK powerbank.

*Please note that the charging speed can be decreased if your screen is turned on.*  
*We suggest not using your devices while charging it.*

### Instructions

You can use the included USB-cable to charge your powerbank using a PC or another 5V USB power supply.

Use the Micro-USB "IN" port to plug in your charging cable.

The powerbank has two USB ports.

You can use both ports at once to charge multiple devices like mobile phones or tablets at the same time.

To show the remaining charge of your powerbank connect a chargeable USB device or press the power button.

*Please note that you can use both ports at once, but the maximum output is 3.5A.*

### Caution

*Do not use in damp environment to avoid damage.*

*The product should be kept away from fire and other high temperature environment to avoid damage and explosions.*

*Do not try to open or repair the device.*

*Do not use a chemical detergent, but a dry cloth for cleaning.*

*Please do not pollute the environment when discarded - try to classify recycling.*

GK Handelsplan GmbH  
Magdeburger Straße 38-40  
47800 Krefeld, Germany

