



ZEAL

Bluetooth headphones

Thanks for choosing our Bluetooth headphones. Please read the whole instruction booklet to ensure the best possible use of your product. Only use the included cables. Hissing could be heard for a short time at the start of the charging process. After not using the headphones for a longer time the battery can be fully discharged. In this case, there can be a delay until the charging LED is flashing. These headphones may need multiple hours until they are fully charged, depending on your power supply.

Product specification

1. Supports all Bluetooth versions, 10m connection, wireless communication (using Bluetooth protocol specifications CLASS 2)
2. Built-In Battery: 3.7V lithium-ion-battery. You can use the included USB cable to charge the headphones at 5V using a PC or another USB power supply.
3. Bluetooth version: 3.0 (A2DP and AVRCP profiles)
4. Works with most Bluetooth-supported devices like tablets or smartphones.
5. It is possible to fold your headphones.

Instructions

1. Turn the headphones on by holding the power button for 3s. The LED will flash blue.
 2. To activate Bluetooth Search, turn off your headphones and hold the power button for 6s until the LED flashes red and blue.
- Activate Bluetooth on your device you want to pair and activate "search for devices".

Connect it to your Bluetooth headphones which are called "ADD-ZEAL".

A sound is played if the connection was successful. You can now play your music using your connected device.

3. Press pause/play to pause a playing song or to continue playing a song. Choose your music by pressing the next/previous buttons. You can change volume by holding the next/previous buttons.

Note that the headphones use independent volume settings. If the music you hear is too quiet, increase the volume on your device the music is played from.

4. To use the headphones without Bluetooth you can use an audio cable to directly connect a media device using the Line-In port.

Caution

Do not use in damp environment to avoid damage.

The product should be kept away from fire and other high temperature environment to avoid damage and explosions.

Continuously high volume can cause permanent hearing damage.

Do not try to open or repair the headphones.

Do not use a chemical detergent, but a dry cloth for cleaning.

Please do not pollute the environment when discarded - try to classify recycling.

GK Handelsplan GmbH
Magdeburger Straße 38-40
47800 Krefeld, Germany

