



SPLASH

Bluetooth in-ear headphones

Thanks for choosing our Bluetooth headphones. Please read the whole instruction booklet to ensure the best possible use of your product. Only use the included cables. Hissing could be heard for a short time at the start of the charging process. After not using the headphones for a longer time the battery can be fully discharged. In this case, there can be a delay until the charging LED is flashing. These headphones need about one hour until they are fully charged, depending on your power supply.

Product specification

1. Supports all Bluetooth versions, 10 m connection (2.4-2.48GHZ)
2. Built-In Battery: 3.7V lithium-ion-battery. You can use the included USB cable to charge the headphones at 5V using a PC or another USB power supply.
3. Bluetooth Version: 4.1 (A2DP / HFP / HSP / AVRCP)
4. Works with most Bluetooth-supported devices like tablets or smartphones.
5. box contents: 2x headphones, 6x silicon tips (S/M/L), charging cable, charging station

Instructions

1. Turn off Bluetooth on your device, before pairing both headphones. Then press the touch area on both earbuds for 6s. A sound will be played and the LED will glow blue if the connection was successful.
2. Activate Bluetooth on your device you want to pair and activate "search for devices". Connect it to your Bluetooth headphones which are called "ADD-SPLASH".

Another sound is played if the connection was successful. You can now play your music using your connected device.

3. Press the touch area to play or pause a song.

Hold the touch area for 2s to skip a song.

4. Press the touch area to answer a call.

Press the touch area twice to hang up.

Hold the touch area for 2s to reject a call.

5. Hold the touch area for 6s to turn your headphones on / off.

Note that the headphones use independent volume settings. If the music you hear is too quiet, increase the volume on your device the music is played from.

Caution

Do not use in damp environment to avoid damage.

The product should be kept away from fire and other high temperature environment to avoid damage and explosions.

Continuously high volume can cause permanent hearing damage.

Do not try to open or repair the headphones.

Do not use a chemical detergent, but a dry cloth for cleaning.

Please do not pollute the environment when discarded - try to classify recycling.



GK Handelsplan GmbH
Magdeburger Straße 38-40
47800 Krefeld, Germany